


TOTE LOAD SYSTEM TOTE LOAD SYSTEM



VACUUM TRANSFER SYSTEM

SCALE HOPPER

SCALE HOPPER

ELECTRICAL CONTROL

DIRECTIONAL VALVE

SCALE HOPPER

SCALE HOPPER

ITEM	QTY.	PART DESCRIPTION	PART NO.
BILL OF MATERIALS			
TOLERANCES: <small>UNLESS OTHERWISE SPECIFIED</small> FRACTIONS ± TOL. .X ± .XX ± .XXX ± NOTE: <small>UNLESS OTHERWISE SPECIFIED, ALL DIMS ARE INCHES.</small>		CASA HERRERA Inc. 2655 NORTH PINE STREET POMONA, CALIFORNIA 91767	
B-size SCALE:		DWG. BY: _____ DATE: _____	MACHINE NAME: _____ REV. _____
MATERIAL:		DESIGN BY: _____ DATE: _____	FILE NO: _____ SHEET NO. _____
		CHK. BY: _____ DATE: _____	DWG. NO: _____ OF _____